

# All Porsche 981 Boxster & Cayman Models Stainless Steel Sports Rear Grille Set Kit

## Kit Contents: -

2. off Rear Grille



## YouTube Tutorial:

<https://www.youtube.com/watch?v=q8aqp1CavdM>

## Rear Mesh Grille Fitting Instructions

1. Fit masking tape around the apertures to protect the paintwork while fitting.
2. Locate Outer upper fixing bracket behind the aperture (Fig 1).
3. Flex and carefully guide the grille so that inner upper bracket locates behind the aperture.
4. Using a thin screwdriver through the mesh lever the 2 brackets so that they have clipped behind the aperture and the grille is secured tightly into position (Fig 2).
5. Repeat for opposite side grille.
6. Remove the tape and the grilles are now complete.



Fig 1



Fig 2